
# **INSTALLATION INSTRUCTIONS**

### **VOLVO T-RIDE V-ROD STRADDLE BUSHINGS**


(ATRO PART NUMBERS TS96-22286, TS96-22600, AND TS96-22700)

- 1) Remove old bushing(s) from rod eye.
  - Using the small diameter end of the ATRO PT96-52200 tool and a hydraulic press, apply pressure to the bushing as shown below. This will remove pressure from the retaining ring.
  - While maintaining pressure on the bushing, remove the retaining ring with snap ring pliers.
  - Release pressure from bushing and remove from rod eye.



#### 2) Bushing Installation (Recommended Method)

- Thoroughly clean inside of rod eye remove any excess rust or debris.
- Using a file or alternate method, remove any burrs and sharp edges from leading edge of rod eye.
- Assemble the 2-piece ATRO# PT96-52200 installation tool and bushing as shown in the picture below. The support sleeve first slides over the press tool, then the press tool/support sleeve assembly is placed on top of the bushing.
  - NOTE: The purpose of the support sleeve is to prevent excessive bulging of the split steel outer sleeve during installation.
- Using a hydraulic press, install bushing into rod eye until fully seated.
- Install the retaining ring that was included with the new ATRO bushing.



- CONTINUED -

## **INSTALLATION INSTRUCTIONS**



## **VOLVO T-RIDE V-ROD STRADDLE BUSHING**

-CONTINUED-

(ATRO PART NUMBERS TS96-22286, TS96-22600, AND TS96-22700)

- 3) Bushing Installation (Alternate Method)
  - Thoroughly clean inside of rod eye remove any excess rust or debris.
  - Using a file or alternate method, remove any burrs and sharp edges from leading edge of rod eye.
  - Install a two piece, 3" shaft collar onto one end of the bushing outer sleeve as shown below. (Shaft collars can be purchased at hardware suppliers)
  - Tighten shaft collar to slightly pre-compress the bushings' split outer sleeve.
  - Using a 2 15/16" OD piece of tube and hydraulic press, install bushing into rod eye until fully seated.
    - (NOTE: There is no need to remove the shaft collar the tube will pass through it during the pressing operation.
  - Install the retaining ring that was included with the new ATRO bushing.

